

C:\Documents and Settings\Administrator\桌面\MIC_IC-V8000.pcb (Silkscreen, Top layer)